# **Rockchip Developer Guide Linux WDT**

ID: RK-KF-YF-083

Release Version: V1.2.0

Release Date: 2023-01-15

Security Level: □Top-Secret □Secret □Internal ■Public

#### **DISCLAIMER**

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD.("ROCKCHIP")DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

### **Trademark Statement**

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

### All rights reserved. ©2023. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: <u>www.rock-chips.com</u>

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: <u>fae@rock-chips.com</u>

### **Preface**

### **Overview**

When the count value of WDT is reduced to 0, a reset signal is generated to reset the system to prevent the system from being stuck due to software.

### **Product Version**

Chipset	Kernel Version	
ALL	Kernel 4.4 & 4.19 & 5.10	

### **Intended Audience**

This document (this guide) is mainly intended for:

Technical support engineers

Software development engineers

### **Revision History**

Version	Author	Date	Change Description
V1.0.0	Simon.Xue	2019-12-23	Initial version
V1.1.0	Simon.Xue	2021-04-13	Add RK356X stop counting function
V1.1.1	Simon.Xue	2023-01-15	Fix format
V1.2.0	Simon.Xue	2023-01-15	Add RK3588 stop counting function

### **Contents**

### **Rockchip Developer Guide Linux WDT**

WDT Driver
DTS Node Configuration
WDT Usage
Kernel Configuration
FAQ
WDT Can't Stop
WDT Accuracy
RK3568 Pause Counting
RK3588 Pause Counting

### **WDT Driver**

The driver file is in:
drivers/watchdog/dw\_wdt.c

# **DTS Node Configuration**

The reference document for DTS configuration is Documentation/devicetree/bindings/watchdog/dw\_wdt.txt, this document mainly introduces the follow parameter:

• interrupts = <GIC\_SPI 120 IRQ\_TYPE\_LEVEL\_HIGH 0>;

The interrupt mode is to trigger an interrupt first, and then generate a reset signal after a timeout period.

clocks = <&cru PCLK\_WDT>;

This attribute function is to drive WDT to work, and calculate each counting cycle.

# **WDT Usage**

The application operates the /dev/watchdog node to control the watchdog. Examples are as follows:

```
int main(void)
   int fd = open("/dev/watchdog", O_WRONLY); //here through open to start
watchdog
   int ret = 0;
   if (fd == -1) {
        perror("watchdog");
       exit(EXIT_FAILURE);
   }
   while (1) {
        ret = write(fd, "\0", 1);  //Feed dogs by write
       if (ret != 1) {
           ret = -1;
           break;
        }
        sleep(10);
   close(fd);
   return ret;
}
```

### About close()

1. Under normal condition, executing close (), which no longer feeding the dog and watchdog restart automatically.

echo A > /dev/watchdog , where any characters other than character V are written

2. write (fd," v ", 1); Then close (), write uppercase V, the kernel continues to feed the dog, the system will not automatically restart.

```
echo V > /dev/watchdog
```

3. Configure the macro CONFIG\_WATCHDOG\_NOWAYOUT, repeat step 2, the kernel will not continue to feed the dog, and the system will be restarted.

# **Kernel Configuration**

```
Symbol: WATCHDOG [=y]
Type : boolean
Prompt: Watchdog Timer Support
    Location:
(1) -> Device Drivers
    Defined at drivers/watchdog/Kconfig:6
```

## **FAO**

# **WDT Can't Stop**

The legacy version of WDT does not have a matched register to configure the stop function, which can only be stopped by disable clock or soft reset. The clock or reset operation of some Rockchip's product can only be performed in a safe environment. The new version of WDT adds a stop function in the future.

## **WDT Accuracy**

The accuracy of WDT is only 16 levels, and the counting of adjacent level is quite different, so it cannot be counted finely.

```
0000: 0x0000ffff
0001: 0x0001ffff
0010: 0x0003ffff
0011: 0x0007ffff
0100: 0x000fffff
0101: 0x001fffff
0110: 0x003fffff
0111: 0x007fffff
1000: 0x00ffffff
1001: 0x01ffffff
1010: 0x03ffffff
1011: 0x07ffffff
1100: 0x0fffffff
1101: 0x1fffffff
1110: 0x3fffffff
1111: 0x7fffffff
```

Assuming that the wdt clock is 100MHz, the maximum timeout time is 0x7fffffff/100MHz = 21 seconds. If a larger timeout is required, the corresponding WDT clock needs to be adjusted.

## **RK3568 Pause Counting**

RK356X add pause counting function, use io command that from Rockchip or busybox's devmem to test pause counting and resume counting.

enable

```
CONFIG_DEVMEM
```

disable

```
CONFIG_STRICT_DEVMEM
```

Address 0xfdc60504 belongs to the register GRF\_SOC\_CON1 of SYS\_GRF. write 0x1 to bit4 pause counting, write 0x0 to bit4 resume counting. Higher 16 bits are writable mask bits.

pause counting.

```
io -4 0xfdc60504 0x00100010
```

or

```
busybox devmem 0xfdc60504 32 0x00100010
```

resume counting.

```
io -4 0xfdc60504 0x00100000
```

or

busybox devmem 0xfdc60504 32 0x00100000

# **RK3588 Pause Counting**

pause counting

```
io -4 0xfd58c000 0x00010001
```

or

busybox devmem 0xfd58c000 32 0x00010001

resume counting

io -4 0xfd58c000 0x00100000

or

busybox devmem 0xfd58c000 32 0x00100000