

# Rockchip RK3588 User Guide eDP

---

文件标识: RK-YH-YF-303

发布版本: V1.0.1

日期: 2022-07-13

文件密级: 绝密 秘密 内部资料 公开

## 免责声明

本文档按“现状”提供, 瑞芯微电子股份有限公司 (“本公司”, 下同) 不对本文档的任何陈述、信息和内容的准确性、可靠性、完整性、适销性、特定目的性和非侵权性提供任何明示或暗示的声明或保证。本文档仅作为使用指导的参考。

由于产品版本升级或其他原因, 本文档将可能在未经任何通知的情况下, 不定期进行更新或修改。

## 商标声明

“Rockchip”、“瑞芯微”、“瑞芯”均为本公司的注册商标, 归本公司所有。

本文档可能提及的其他所有注册商标或商标, 由其各自拥有者所有。

## 版权所有 © 2021 瑞芯微电子股份有限公司

超越合理使用范畴, 非经本公司书面许可, 任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部, 并不得以任何形式传播。

瑞芯微电子股份有限公司

Rockchip Electronics Co., Ltd.

地址: 福建省福州市铜盘路软件园A区18号

网址: [www.rock-chips.com](http://www.rock-chips.com)

客户服务电话: +86-4007-700-590

客户服务传真: +86-591-83951833

客户服务邮箱: [fae@rock-chips.com](mailto:fae@rock-chips.com)

---

## 前言

文本主要介绍RK3588芯片eDP模块的软件配置与调试方法。

## 读者对象

本文档 (本指南) 主要适用于以下工程师:

技术支持工程师

软件开发工程师

## 修订记录

版本号	作者	修改日期	修改说明
V1.0.0	闭伟勇	2022-01-14	初始发布
V1.0.1	闭伟勇	2022-07-13	内容更新

## 目录

### Rockchip RK3588 User Guide eDP

Introduction

Feature

Driver

dt-bindings

eDP

外设为Panel, 不支持HPD

外设为Monitor, 支持HPD

HPD FUNC

HPD GPIO

Split-mode

PHY

training table

lane polarity

Panel

hardcode timing

edid timing


logo

调试手段

常见问题

## Introduction

本文档主要描述RK3588芯片eDP模块的软件配置以及调试方法。



## Feature

- DP v1.2
- eDP v1.3
- HDCP v1.3

- 1/2/4 lane
- 5.4/2.7/1.62 Gbps/lane
- Bi-directional auxiliary link with up to 1Mbps speed
- RGB 6/8/10 bit per component video format
- YCbCr 4:4:4, YCbCr 4:2:2 8/10 bit per component video format
- Support PSR
- Support audio

## Driver

eDP Controller 驱动文件路径:

```
kernel:
drivers/gpu/drm/bridge/analogix/analogix_dp_core.c
drivers/gpu/drm/bridge/analogix/analogix_dp_core.h
drivers/gpu/drm/bridge/analogix/analogix_dp_reg.c
drivers/gpu/drm/bridge/analogix/analogix_dp_reg.h
drivers/gpu/drm/rockchip/analogix_dp-rockchip.c
include/drm/bridge/analogix_dp.h

u-boot:
drivers/video/drm/analogix_dp.c
drivers/video/drm/analogix_dp.h
drivers/video/drm/analogix_dp_reg.c
```

eDP PHY 驱动文件路径:

```
kernel:
drivers/phy/rockchip/phy-rockchip-samsung-hdptx.c

u-boot:
drivers/phy/phy-rockchip-samsung-hdptx.c
```

eDP Panel 驱动文件路径:

```
kernel:
drivers/gpu/drm/panel/panel-simple.c


u-boot:
drivers/video/drm/rockchip_panel.c
```

DTS 参考配置文件路径:

```
kernel:
arch/arm64/boot/dts/rockchip/rk3588s-evb1-1p4x.dtsi
arch/arm64/boot/dts/rockchip/rk3588-evb2-1p4-v10-edp2dp.dts
```

## dt-bindings

---



NOTE: eDP的输入源可以选择VP0/VP1/VP2, 优先选择VP2。

## eDP

### 外设为Panel, 不支持HPD

```

&edp0 {
    force-hpd;
    status = "okay";

    ports {
        port@1 {
            reg = <1>;

            edp0_out_panel: endpoint {
                remote-endpoint = <&panel_in_edp0>;
            };
        };
    };
};

&edp0_in_vp0 {
    status = "disabled";
};

&edp0_in_vp1 {
    status = "disabled";
};

&edp0_in_vp2 {
    status = "okay";
};
  
```

### 外设为Monitor, 支持HPD

#### HPD FUNC

hdmim0\_tx0\_hpd (gpio1\_a5)

hdmim1\_tx0\_hpd (gpio3\_d4)

```

&edp0 {
  
```

```

pinctrl-names = "default";
pinctrl-0 = <&hdmim0_tx0_hpd>;
status = "okay";
};

&edp0_in_vp0 {
    status = "disabled";
};

&edp0_in_vp1 {
    status = "disabled";
};

&edp0_in_vp2 {
    status = "okay";
};

```

## HPD GPIO

```

&edp0 {
    pinctrl-names = "default";
    pinctrl-0 = <&edp0_hpd>;
    hpd-gpios = <&gpio1 RK_PA5 GPIO_ACTIVE_HIGH>;
    status = "okay";
};

&pinctrl {
    edp {
        edp0_hpd: edp0-hpd {
            rockchip,pins = <1 RK_PA5 0 &pcfg_pull_none>;
        };
    };
};


&edp0_in_vp0 {
    status = "disabled";
};

&edp0_in_vp1 {
    status = "disabled";
};

&edp0_in_vp2 {
    status = "okay";
};

```

## Split-mode



```
diff --git a/arch/arm64/boot/dts/rockchip/rk3588s-evb1-1p4x.dtsi
b/arch/arm64/boot/dts/rockchip/rk3588s-evb1-1p4x.dtsi
index 8eb4fcf75aae..7b92b00d3759 100644
--- a/arch/arm64/boot/dts/rockchip/rk3588s-evb1-1p4x.dtsi
+++ b/arch/arm64/boot/dts/rockchip/rk3588s-evb1-1p4x.dtsi
@@ -223,6 +223,7 @@
};

&edp0 {
+   split-mode;
   force-hpd;
   status = "okay";
};
```

NOTE: split-mode要求edp0和edp1的timing完全一样，最好是两个一样的屏。

## PHY

```
&hdptxphy0 {
    status = "okay";
};

&hdptxphy_hdmi0 {
    status = "disabled";
};
```

NOTE: 因为hdptxphy是combo的，hdmi和edp功能二选一，所以需要确保对应hdptxphy\_hdmi节点是disabled状态。

## training table

可选属性，一般不需要配置，使用驱动默认参数。如果眼图不符合要求，可以配置以下属性，使用单一参数配置，调整相关参数使眼图达标。

```
&hdptxphy0 {
    /* Single Vdiff Training Table (optional) */
    training-table = /bits/ 8 <
        /* voltage swing 0, pre-emphasis 0->3 */
        0x0d 0x0a 0x04 0x06 0x00 0x04
        0x0d 0x0a 0x04 0x06 0x00 0x04
        0x0d 0x0a 0x04 0x06 0x00 0x04
        0x0d 0x0a 0x04 0x06 0x00 0x04
        /* voltage swing 1, pre-emphasis 0->2 */
```

```

    0x0d 0x0a 0x04 0x06 0x00 0x04
    0x0d 0x0a 0x04 0x06 0x00 0x04
    0x0d 0x0a 0x04 0x06 0x00 0x04
    /* voltage swing 2, pre-emphasis 0->1 */
    0x0d 0x0a 0x04 0x06 0x00 0x04
    0x0d 0x0a 0x04 0x06 0x00 0x04
    /* voltage swing 3, pre-emphasis 0 */
    0x0d 0x0a 0x04 0x06 0x00 0x04
};
status = "okay";
};

```

第一列参数含义:

```

1n_tx_drv_lvl_ctrl
TX driver main-tap level (TX_AMP)
01101: max main-tap level(max swing)
...
00000: min main-tap level(min swing)
others: N/A

```

第二列参数含义:

```

1n0_tx_drv_post_lvl_ctrl
TX driver de-emphasis level (TX_DE_EMP)
0000: min de-emphasis level
...
1110: max de-emphasis level
others: N/A

```

## lane polarity

可选属性，一般不需要配置。如果硬件设计上，LANEx的P/N极性需要反向，可以配置该属性。

```

&hdptxphy0 {
    lane-polarity-invert = <0 1 0 0>;
    status = "okay";
};

```

## Panel

### hardcode timing

```

/ {
    panel-edp0 {
        compatible = "simple-panel";
        backlight = <&backlight>;
        power-supply = <&vcc3v3_lcd_edp0>;
        prepare-delay-ms = <120>;
        enable-delay-ms = <120>;
        unprepare-delay-ms = <120>;
        disable-delay-ms = <120>;
        width-mm = <129>;
        height-mm = <171>;
    };
};

```

```

panel-timing {
    clock-frequency = <200000000>;
    hactive = <1536>;
    vactive = <2048>;
    hfront-porch = <12>;
    hsync-len = <16>;
    hback-porch = <48>;
    vfront-porch = <8>;
    vsync-len = <4>;
    vback-porch = <8>;
    hsync-active = <0>;
    vsync-active = <0>;
    de-active = <0>;
    pixelclk-active = <0>;
};

port {
    panel_in_edp0: endpoint {
        remote-endpoint = <&edp0_out_panel>;
    };
};
};
};

```

property	description	value
power-supply	Display panels require power to be supplied.	
enable-gpios	Specifier for a GPIO connected to the panel enable control signal.	
reset-gpios	Specifier for a GPIO connected to the panel reset control signal.	
bus-format	Pixel data format	<b>MEDIA_BUS_FMT_RGB888_1X24</b> / MEDIA_BUS_FMT_RGB666_1X24_CPADHI / MEDIA_BUS_FMT_RGB101010_1X30
bpc	Bits per color	<b>8/6/10</b>
width-mm	Physical width in mm	
height-mm	Physical height in mm	

## edid timing

```

/ {
    panel-edp0 {
        compatible = "simple-panel";
        backlight = <&backlight>;
        power-supply = <&vcc3v3_lcd_edp0>;
    };
};

```



```

prepare-delay-ms = <120>;
enable-delay-ms = <120>;
unprepare-delay-ms = <120>;
disable-delay-ms = <120>;

port {
    panel_in_edp0: endpoint {
        remote-endpoint = <&edp0_out_panel>;
    };
};
};
};
};

```

## logo


```

&route_edp0 {
    connect = <&vp2_out_edp0>;
    status = "okay";
};

```

NOTE: 调试的时候建议关闭, 待调试完成, panel已经正常显示之后, 再打开logo。

## 调试手段



1、确认当前连接状态:

```

console:/ # cat /sys/class/drm/card0-eDP-1/status
connected

```

如果status为disconnected, 可能是hpd为low或者aux无法通信。

2、确认显示路径当前状态:

```

console:/ # cat /d/dri/0/summary
Video Port1: DISABLED
Video Port2: ACTIVE
Connector: eDP-1
    bus_format[100a]: RGB888_1X24
    overlay_mode[0] output_mode[f] color_space[0]
Display mode: 1536x2048p60
    clk[200000] real_clk[200000] type[48] flag[a]

```

```
H: 1536 1548 1564 1612
V: 2048 2056 2060 2068
Cluster2-win0: ACTIVE
win_id: 4
format: AB24 little-endian (0x34324241)[AFBC] SDR[0] color_space[0]
glb_alpha[0xff]
rotate: xmirror: 0 ymirror: 0 rotate_90: 0 rotate_270: 0
csc: y2r[0] r2y[0] csc mode[0]
zpos: 0
src: pos[0, 0] rect[1536 x 2048]
dst: pos[0, 0] rect[1536 x 2048]
buf[0]: addr: 0x000000001677000 pitch: 6144 offset: 0
```

### 3、使能panel自测模式

```
diff --git a/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
b/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
index a95bd09749db..4888d2aeadd2 100644
--- a/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
+++ b/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
@@ -223,6 +223,7 @@
    };

    &edp0 {
+       panel-self-test;
        force-hpd;
        status = "okay";
```

如果使能panel自测模式后，panel可以显示，那么说明panel已经正常工作，aux可以正常通信。

### 4、使能edp自测模式

```
diff --git a/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
b/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
index a95bd09749db..27c93ce92947 100644
--- a/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
+++ b/arch/arm64/boot/dts/rockchip/rk3588s-evb1-lp4x.dtsi
@@ -223,6 +223,7 @@
    };

    &edp0 {
+       analogix,video-bist-enable;
        force-hpd;
        status = "okay";
```

如果使能edp自测模式后，panel可以显示，那么说明panel已经正常工作，aux可以正常通信，edp主链路正常。

## 常见问题

### 1、backlight驱动probe失败

```
console:/ # dmesg | grep backlight
[ 3.164274] pwm-backlight: probe of backlight failed with error -16
```

一般原因是backlight节点下的配置与其他模块存在资源冲突。

## 2、panel驱动probe失败

```
console:/ # dmesg | grep panel
[ 3.156813] panel-simple panel-edp: failed to get enable GPIO: -16
[ 3.156919] panel-simple: probe of panel-edp failed with error -16
```

一般原因是panel节点下的配置与其他模块存在资源冲突。

## 3、aux通信报错:

```
console:/ # dmesg | grep edp
[ 3.236549] rockchip-dp fdec0000.edp: failed to read max link rate
[ 3.260422] rockchip-dp fdec0000.edp: failed to read max link rate
[ 3.284163] rockchip-dp fdec0000.edp: failed to read max link rate
```

该log说明通过AUX读取DPCD失败，一般是panel没有正常工作导致无应答，需要检查panel的供电。